



TRACK LUG HEIGHT TO STUD LENGTH APPLICATION CHART										
Lug Height (varies +/- .030")	Track Belt Thickness	Suggested Stud Size	Stud Penetration Above Lug (varies +/- .030")	Support Nut Suggested	Stud O.A.L.	"Power Point" Part Number	"Power Point" Stainless Part Number	"SPT" Part Number	 "Power Point" +PLUS	 "Lake Racer"
.725"	.230"	.875"	.405"-.435"	na	1.318"	2024-qty	2207-qty	2211-qty	na	na
.750"	.230"	.875"	.380"-.410"	na	1.318"	2024-qty	2207-qty	2211-qty	na	na
.820"	.230"	.875"	.310"-.340"	na	1.318"	2024-qty	2207-qty	2211-qty	na	na
	.230"	.960"	.375"-.405"	na	1.348"	2165-qty	na	na	na	na
	.230"	1.000"	.435"-.465"	na	1.448"	2022-qty	2208-qty	2212-qty	na	na
.850"	.230"	.875"	.280"-.310"	na	1.318"	2024-qty	2207-qty	2211-qty	na	na
	.230"	.960"	.365"-.395"	na	1.348"	2165-qty	na	na	na	na
	.230"	1.000"	.405"-.430"	na	1.448"	2022-qty	2208-qty	2212-qty	na	na
.880"	.230"	.875"	.250"-.280"	na	1.318"	2024-qty	2207-qty	2211-qty	na	na
	.230"	.960"	.335"-.365"	na	1.348"	2165-qty	na	na	na	na
	.230"	1.000"	.375"-.405"	na	1.448"	2022-qty	2208-qty	2212-qty	na	na
	.230"	1.080"	.455"-.485"	.500"	1.523"	2025-qty	2209-qty	2213-qty	na	na
.910"	.230"	1.000"	.345"-.375"	na	1.448"	2022-qty	2208-qty	2212-qty	na	na
	.230"	1.080"	.425"-.455"	.500"	1.523"	2025-qty	2209-qty	2213-qty	na	na
.920"	.250"	1.000"	.335"-.365"	na	1.448"	2022-qty	2208-qty	2212-qty	na	na
	.250"	1.080"	.415"-.445"	.500"	1.523"	2025-qty	2209-qty	2213-qty	na	na
1.000"	.230"	1.000"	.255"-.285"	na	1.448"	2022-qty	2208-qty	2212-qty	na	na
	.230"	1.080"	.335"-.365"	na	1.523"	2025-qty	2209-qty	2213-qty	2435-qty	na
	.230"	1.187"	.442"-.472"	.500"	1.630"	2067-qty	2349-qty	2348-qty	na	na
	.230"	1.280"	.535"-.565"	.500"	1.695"	2428-qty	na	na	na	na
1.100"	.230"	1.187"	.342"-.372"	na	1.630"	2067-qty	2349-qty	2348-qty	2436-qty	2440-qty
1.250"	.230"	1.280"	.285"-.315"	.500"	1.695"	2428-qty	na	na	na	2441-qty
	.230"	1.375"	.375"-.405"	.750"	1.755"	2166-qty	2210-qty	na	2437-qty	2442-qty
1.375"	.230"	1.500"	.375"-.405"	.750"	1.885"	2248-qty	na	na	2485-qty	2443-qty
1.500"	.230"	1.625"	.375"-.405"	.750"	1.980"	2267-qty	na	na	2486-qty	na
1.625"	.230"	1.750"	.375"-.405"	.750"	2.115"	2337-qty	na	na	na	na
1.750"	.230"	1.875"	.375"-.405"	.750"	2.230"	2350-qty	na	na	na	na

"STUD BOY"[®] recommends for trail applications that you use .250"-.400" stud penetration. Penetration outside of this range can result in loss of control and damage to your snowmobile and/or traction products.

- * Be sure that you always check your snowmobile for proper stud clearance.
- * Be sure to install the proper steering carbide to the amount of studs installed.

