

STUD BOY APPLICATION CHART

ARCTIC CAT 2000

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2000 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Bearcat 340	0.750		0.875	81	0.875	108	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Bearcat 440-I	0.920	15x136	0.960	81	0.960	108	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Bearcat 440-II	1.000	15x156	1.000	93	1.000	124	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Bearcat 550 WT	1.000	15x156	1.000	93	1.000	124	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Pantera 550	0.750	15x136	0.875	108	0.875	135	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Pantera 580	0.750	15x136	0.875	108	0.875	135	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Pantera 1000	0.750	15x136	0.875	135	0.875	162	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Panther 340	0.750	15x136	0.875	81	0.875	108	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Panther 440	0.750	15x136	0.875	81	0.875	108	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Powder Special 500/EFI	1.400	15x136	NA	NA	NA	NA	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Powder Speical 600/EFI	2.000	15x136	NA	NA	NA	NA	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Powder Special 700	2.000	15x136	NA	NA	NA	NA	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Thundercat	0.850	15x121	1.000	144/168	1.080	192/240	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Thundercat MC	2.000	15x136	NA	NA	NA	NA	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
Z 370 / ES	0.750	15x121	0.875	72/96	0.960	96/120	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Z 440 / ES	0.750	15x121	0.875	96	0.960	120	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
ZL 440	0.750	15x121	0.875	96	0.960	120/144	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
ZL 500 / EFI	0.850	15x121	1.000	96/120	1.0/1.080	144	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
ZL 580/EFI /ZL550/ESR	0.850	15x121	1.000	96/120	1.080	120/144	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
ZL 600 / EFI	0.850	15x121	1.000	96/120	1.080	144	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
ZR 500 / EFI	0.850	15x121	1.000	96/120	1.080	120/144	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
ZR 600 / EFI	0.850	15x121	1.000	96/120	1.080	144/168	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
ZR 700 / ZL 700	0.850	15x121	1.000	120/144	1.080	168/162	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
ZRT 600	0.850	15x121	1.000	120/144	1.080	192	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)
ZRT 800	0.850	15x121	1.000	144/168	1.080	192/240	CAT-D2093-(add size)	CAT-R2093-(add size)	CAT-S2093-(add size)

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.