

STUD BOY APPLICATION CHART

SKI DOO 2000

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2000 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Formula 380 DLX	0.720	15x121	0.875	72	0.875	96/120	NA	DOO-R2146-(add size)	NA
Formula 500 DLX	0.720	15x121	0.875	96	0.875	120	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Formula 500 DLX LC	0.720	15x121	0.875	96	0.875	120	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Formula 600 DLX	0.880	15x121	1.000	120	1.000	144/168	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Formula 700 DLX	0.880	15x121	1.000	144	1.000	168/192	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Formula III 700	0.880	15x121	1.000	144	1.000	168/192	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Formula S	0.720	15x121	0.875	72	0.875	96	NA	DOO-R2146-(add size)	NA
Formula 500 LC	0.720	15x121	0.875	96	0.875	120/144	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Formula Z 700	0.880	15x121	1.000	144	1.000	168/192	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Touring 500 LC	0.720	15x136	0.875	81	0.875	108/135	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Grand Touring 600	0.880	15x136	1.000	108	1.000	162	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Grand Touring 700	0.880	15x136	1.000	135	1.000	162	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Grand Touring SE	0.880	15x136	1.000	135	1.000	162	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Mach 1	0.880	15x121	1.000	144	1.000	168/192	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Mach Z	0.880	15x121	1.000	144/168	1.000	192/240	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
MX Z 440	0.720	15x121	0.875	96	0.875	120/144	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
MX Z 500	0.880	15x121	1.000	96	1.000	120/144	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
MX Z 600	0.880	15x121	1.000	120	1.000	144/168	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
MX Z 700	0.880	15x121	1.000	144	1.000	168/192	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Skandic 380	0.910	15x136	1.000	81	1.000	108	NA	DOO-R2146-(add size)	NA
Skandic 500	0.910	15x136	1.000	81	1.000	108	NA	DOO-R2146-(add size)	NA
Skandic SWT	0.910	24x156	1.000	91	1.000	91	NA	DOO-R2146-(add size)	NA
Skandic WT	0.910	20x156	1.000	91	1.000	91	NA	DOO-R2146-(add size)	NA
Skandic WT LC	0.910	20x156	1.000	91	1.000	91/122	NA	DOO-R2146-(add size)	NA
Summit 500	1.450	15x136	Na	Na	NA	NA	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Summit 600	1.750	15x136	Na	Na	NA	NA	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Summit 700	2.000	15x136	Na	Na	NA	NA	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Touring E	0.720	15x136	0.875	81	108.000	108	NA	DOO-R2146-(add size)	NA
Touring LE	0.720	15x136	0.875	81	108.000	108	NA	DOO-R2146-(add size)	NA
Touring SLE	0.720	15x136	0.875	81	108.000	108	NA	DOO-R2146-(add size)	NA

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS - NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.