

STUD BOY APPLICATION CHART

POLARIS 2001

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2001 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
340 / DLX	0.660	15x121	0.875	72	0.875	72	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
340 TOURING	1.000	15x133.5	1.080	80	1.080	106	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
500 XC	0.820	15x121	0.960	96	1.000	120/144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
500 XC/SP	0.910	15x121	1.000	96	1.080	120/144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
500 Indy	0.820	15x121	0.960	96	1.000	120/144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
500 Classic	0.820	15x121	0.960	96	1.000	120/144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
500 RMK	1.500	15x136	NA	NA	NA	NA	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
500Classic Tour	0.820	15x133.5	0.960	106	1.000	132/159	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
600 XC/SP	0.910	15x121	1.000	96/120	1.080	144/168	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
600 Classic	1.000	15x121	1.080	96/120	1.080	144/168	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
600 RMK	1.750	15x136	NA	NA	NA	NA	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
600Classic Tour	0.820	15x133.5	0.960	106	1.000	132/159	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
700 XC / SP	0.910	15x121	1.000	120/144	1.080	168/192	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
700 RMK	1.75/2.	15x136	NA	NA	NA	NA	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
700 SKS	1.250	15x136	1.375	108	1.375	135/162	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
700 Classic	1.000	15x121	1.080	120/144	1.080	144/168	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
800 XC/SP/LE	0.910	15x121	1.080	144/168	1.080	192/240	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
800 RMK	2.000	15x144	NA	NA	NA	NA	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
800 XCR	0.910	15x121	1.000	144/168	1.080	192/240	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
SportTour / ES	1.000	15x136	1.080	81	1.080	108	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
Super Sport	0.820	15x121	0.960	72/96	1.000	120/144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
Trail RMK	1.250	15x136	1.375	81	1.375	108	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
WideTrak LX	1.000	20x156	1.080	84	1.080	124	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
Indy XCF SP	0.820	15x121	0.960	96	1.000	120/144	POL-D1225-(add size)	POL-R1225-(add size)	POL-S1225-(add size)
120 XC SP	0.710	10X69	TBA	TBA	TBA	TBA	NA	POL-R2219-(add size)	NA

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized.

Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you

ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for

safe and proper handling. If you are not using studs do not install overly aggressive wearbars.