

STUD BOY APPLICATION CHART

SKI DOO 2004

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2004 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Elite	0.88	2-15x136	1	144/192	N/A	N/A	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
MX-Z-Fan 380	0.72	15x121	0.875	72	0.875	96	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
MX-Z Fan 550	0.88	15x121	1	96	1	144	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Rev-MXZ Trail 500/600	1	15x121	1.08	96	1.08	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Rev-Adrenaline 5/600	1	15x121	1.08	96	1.08	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Rev - Adrenaline 800	1	15X121	1.08	144	1.08	168/192	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Rev – Renegade 600	1.25	15x136	1.375	108	1.375	162	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
REV - Renegade 800	1.25	15x136	1.375	162	1.375	189/216	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Summit Fan	1.5	15x136	1.625	81	1.625	108/135	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
REV-Summit Adrenaline 600 & 800	2	16X144	N/A	N/A	N/A	N/A	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
REV- Summit Sport & Highmark 151	2	16X151	N/A	N/A	N/A	N/A	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Skandic Sport	1.25	15x136	1.375	81	1.375	108	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Skandic SUV	1.25	20x156	1.375	93	1.375	124	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Skandic SWT	1	24x156	1.08	93	1.08	124	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
Skandic LT	1	15x156	1.08	93	1.08	108	NA	DOO-R2146-(add size)	NA
Skandic WT	1.25	20x156	1.375	93	1.375	108	NA	DOO-R2146-(add size)	NA
Skandic Tundra	0.73	15x139	0.875	83	0.875	110	NA	DOO-R2146-(add size)	NA
Legend Fan 380	0.72	15x121	0.875	72	0.875	96	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Legend Fan 550	0.88	15x121	1	96	1	144	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Legend Sport 500/600	0.88	15x121	1	96	1	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend Sport 700/1000	0.88	15x121	1	144	1	168/192	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend SE 600/700	0.88	15x121	1	96	1	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend SE 800/1000	0.88	15x121	1	144	1	168/192	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
GSX Sport 500/600	1	15x121	1.08	96	1.08	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
GSX Limited 600	1	15x121	1.08	96	1.08	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
GSX Limited 800	1	15x121	1.08	144	1.08	168	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend GT – Fan 380	0.72	15x121	0.875	72	0.875	96	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend GT – Fan 550	0.88	15x121	1	96	1	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend GT Sport 500	0.88	15x121	1	96	1	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend GT Sport 600	0.88	15x121	1	96	1	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend GT Sport 700	0.88	15x121	1	144	1	168/192	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend GT Sport 1000	0.88	15x121	1	144	1	168/192	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend GT – SE 600	0.88	15x121	1	96	1	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend GT – SE 700	0.88	15x121	1	96	1	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend GT – SE 800	0.88	15x121	1	144	1	144	NA	DOO-R2256-(add size)	DOO-S2256-(add size)
Legend GT – SE 1000	0.88	15x121	1	144	1	168/192	NA	DOO-R2256-(add size)	DOO-S2256-(add size)

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.