

# STUD BOY APPLICATION CHART YAMAHA 2004

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2004 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Mountain RX-1	2.000	15x151	NA	NA	NA	NA	YAM-D2226-(add size)	YAM-R2226-(add size)	YAM-S2226-(add size)
Mountain Max 700	2.000	15x141	NA	NA	NA	NA	NA	YAM-R2204-(add size)	YAM-S2204-(add size)
Moutian SX Viper	2.000	15x144	NA	NA	NA	NA	YAM-D2226-(add size)	YAM-R2226-(add size)	YAM-S2226-(add size)
RX-1/RX-1 ER	1.250	15x121	1.375	144/168	1.375	192	YAM-D2226-(add size)	YAM-R2226-(add size)	YAM-S2226-(add size)
RX-1 Warrior	1.250	15x136	1.375	135/162	1.375	189/216	YAM-D2226-(add size)	YAM-R2226-(add size)	YAM-S2226-(add size)
SX Viper ER	1.000	15x121	1.080	144	1.080	168/192	YAM-D2226-(add size)	YAM-R2226-(add size)	YAM-S2226-(add size)
SX Venom							YAM-D2226-(add size)	YAM-R2226-(add size)	YAM-S2226-(add size)
SX Venom ER							YAM-D2226-(add size)	YAM-R2226-(add size)	YAM-S2226-(add size)
SX Viper S	1.250	15x121	1.375	144/168	1.250	192	YAM-D2226-(add size)	YAM-R2226-(add size)	YAM-S2226-(add size)
Venture 600	1.000	15x136	1.080	108	1.080	135	YAM-D2226-(add size)	YAM-R2226-(add size)	YAM-S2226-(add size)
Venture 700	1.250	15x136	1.375	135	1.375	162	YAM-D2226-(add size)	YAM-R2226-(add size)	YAM-S2226-(add size)
VK540 III	1.000	20x156	1.000	93	1.000	93	NA	YAM-R2082-(add size)	NA

\*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**\*\* PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.