

STUD BOY APPLICATION CHART

SKI DOO 2006

| Snowmobile Information | | | Riding Style | | | | Wearbars | | |
|--|------------|--------------|--------------|---------------|-------------|---------------|----------|----------------------|----------------------|
| | | | Safety | | Performance | | | | |
| 2006 Model | Lug Height | Track Length | Stud Length | Stud Quantity | Stud Length | Stud Quantity | Deuce | Round | Shaper |
| Freestyle | 0.720 | 15x121 | 0.875 | 72 | 0.875 | 96 | NA | CAM-R2395-(add size) | CAM-S2395-(add size) |
| Mach Z | 1.000 | 15x121 | 1.080 | 144 | 1.080 | 192 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| Optional Track (spring) | 1.250 | | 1.375 | | 1.375 | | | | |
| MX-Z-Fan 380 | 0.720 | 15x121 | 0.875 | 72 | 0.875 | 96 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| MX-Z Fan 550 | 0.880 | 15x121 | 1.000 | 96 | 1.000 | 144 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| MXZ Trail 500 SS | 1.000 | 15x121 | 1.080 | 96 | 1.080 | 144 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| MXZ 550 X | 1.000 | 15x121 | 1.080 | 96 | 1.080 | 144 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| MXZ Adrenaline 500ss | 1.000 | 15x121 | 1.080 | 96 | 1.080 | 144 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| 600 HO/2TEC 600 SDI Optional Track (spring) | 1.250 | | 1.375 | | 1.375 | | | | |
| MXZ Adrenaline 800 | 1.000 | 15x121 | 1.080 | 144 | 1.080 | 192 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| Optional Track (spring) | 1.250 | | 1.375 | | 1.375 | | | | |
| MXZ Renegade 2-TEC 600 HO SDI | 1.250 | 16x136 | 1.375 | 108 | 1.375 | 162 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| | | | 1.375 | | 189/216 | | | | |
| MXZ Renegade 800 | 1.250 | 16x136 | 1.375 | 162 | 1.625 | 135 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| Summit Fan 550 | 1.500 | 15x136 | 1.625 | 108 | N/A | N/A | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| Summit – 144"/151" Adrenaline 600 & 800 | 2.000 | 16x144 | N/A | N/A | N/A | N/A | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| | | 16x151 | | | 0.875 | 96 | | | |
| Summit Highmark 151 | 2.250 | 16x151 | N/A | N/A | 1.000 | 144 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| 162 | | 16x162 | | | 1.080 | 144 | | | |
| GSX Fan 380 | 0.720 | 15x121 | 0.875 | 72 | 1.080 | 144 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| GSX Fan 550 | 0.880 | 15x121 | 1.000 | 96 | 0.875 | 108 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| GSX Sport 500/600 | 1.000 | 15x121 | 1.080 | 96 | 1.080 | 162 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| GSX Limited 600/800 | 1.000 | 15x121 | 1.080 | 144 | 1.000 | 162 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| GTX Fan 380 | 0.720 | 15x136 | 0.875 | 81 | 1.000 | 162 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| GTX Fan 550 | 0.880 | 15x136 | 1.000 | 108 | 0.875 | 110 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| GTX Sport 500/600 HO | 0.880 | 15x136 | 1.000 | 108 | 1.080 | 108 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| GTX Limited 600/800 | 0.880 | 15x136 | 1.000 | 108 | 1.375 | 108 | NA | DOO-R2410-(add size) | DOO-S2410-(add size) |
| Skandic Tundra | 0.730 | 15x136 | 0.875 | 83 | 1.000 | 124 | NA | CAM-R2395-(add size) | CAM-S2395-(add size) |
| Skandic LT | 1.000 | 15x156 | 1.080 | 93 | 1.375 | 124 | NA | NA | NA |
| Skandic WT | 1.250 | 20x156 | 1.375 | 93 | 1.375 | 162 | NA | NA | NA |
| Skandic SWT | 0.900 | 24x156 | 1.000 | 93 | 1.375 | 124 | NA | NA | NA |
| Skandic SUV | 1.250 | 20x156 | 1.375 | 93 | | | NA | NA | NA |
| Expedition Sport | 1.250 | 16x136 | 1.375 | 108 | | | NA | CAM-R2395-(add size) | CAM-S2395-(add size) |
| Expedition TUV | 1.250 | 20x156 | 1.375 | 93 | | | NA | NA | NA |

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.