

STUD BOY APPLICATION CHART

ARCTIC CAT 2007

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2007 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Bearcat WideTrack	1.000	20x156	1.080	93	1.080	124	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Bearcat WT Turbo/Art.	1.250	20x156	1.375	124	1.375	155	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Bearcat 570	1.000	16x156	1.080	124	1.080	155	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Crossfire 5/6	1.250	15x136	1.375	162	1.375	216	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Crossfire 8/1000	1.250	15x136	1.375	180	1.375	216	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Crossfire 8/1000SnoPro	1.250	15x136	1.375	180	1.375	216	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
F5/F6 & LXR	1.000	15x128	1.080	136	1.187	153/170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
F6 Sno Pro	1.000	15x128	1.080	136	1.187	153/170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
F8/F1000 & LXR	1.000	15x128	1.080	153	1.187	170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
F8/F1000 Sno-Pros	1.000	15x128	1.080	153	1.187	170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Jaguar Z1	1.000	15x128	1.080	153	1.187	170	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Panther 370	1.000	15x136	1.080	81	1.080	108	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Panther 570/660 Tour	1.000	15x136	1.080	108	1.080	135	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Panther 660 Trail	1.000	15x121	1.080	96	1.080	96	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
M6 141/153	2.250	15x141	N/A	N/A	N/A	N/A	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
M8/Sno Pro 141-162	2.250	15x141	N/A	N/A	N/A	N/A	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
M1000/SnoPro 153/162	2.250	15x153	N/A	N/A	N/A	N/A	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
T660 TurboTouring/LE	1.000	15x136	1.080	108	1.080	162	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
T660 Turbo/LE	1.250	15x121	1.375	96	1.375	144	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Z 370 / LX	0.750	15x121	0.875	72/96	0.875	96/120	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
Z 570 / LX	0.850	15x121	1.000	96	1.000	120/144	CAT-D2264-(add size)	CAT-R2264-(add size)	CAT-S2264-(add size)
120	0.500	10X68	N/A	N/A	N/A	N/A	NA	CAT-R2217-(add size)	NA

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.