

STUD BOY APPLICATION CHART

POLARIS 2007

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
2007 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Trail Touring Dlx	1.000	15x136	1.080	108	1.080	108	CAM-D2395-(add size)	CAM-R2395-(add size)	CAM-S2395-(add size)
340 Touring	1.000	15x136	1.080	108	1.080	108	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
Trail RMK 136	1.250	15x136	1.375	108	1.375	108	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
WideTrak LX	1.000	20x156	1.080	93	1.080	124	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
Dragon	1.250	15x121	1.375	144	1.375	192	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
120	0.790	10x69	N/A	N/A	N/A	N/A	NA	POL-R2219-(add size)	NA
340 LX	0.660	15x121	N/A	N/A	N/A	N/A	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
550 LX	0.820	15x121	1.000	96	1.000	120	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
500 XC SP	0.910	15x121	1.000	96	1.000	120/144	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
SuperSport	0.820	15x121	1.000	96	1.000	120	NA	CAM-R2395-(add size)	CAM-S2395-(add size)
FST IQ LX	1.000	15x128	1.080	102	1.080	153	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 HO IQ LX CFI	1.000	15x128	1.080	102	1.080	153	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 HO IQ/CFI	1.000	15x121	1.080	144	1.080	192	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 HO S.Back/CFI	1.250	15x144	1.375	114	1.375	171	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
FST IQ	1.000	15x121	1.080	144	1.080	192	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
FST IQ Cruiser	1.000	15x136	1.080	108	1.080	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
FST Switchback	1.250	15x144	1.375	143	1.375	171	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
FS IQ Touring	1.000	15x136	1.080	108	1.080	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
FST IQ Touring	1.000	15x136	1.080	108	1.080	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
600 HO IQ Touring	1.000	15x136	1.080	108	1.080	162	POL-D2370-(add size)	POL-R2370-(add size)	POL-S2370-(add size)
RMK Dragon	2.400	15x155	N/A	N/A	N/A	N/A	NA	NA	POL-S2484-(add size)
600 HO RMK 155	2.400	15x155	N/A	N/A	N/A	N/A	NA	NA	NA
600 HO RMK 144	2.000	15X144	N/A	N/A	N/A	N/A	NA	NA	NA

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized.

Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you

ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced

for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.