

STUD BOY APPLICATION CHART

SKI DOO 1997

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
1997 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Formula 500	0.725	15x121	0.875	96	0.875	120	NA	DOO-R2144-(add size)	NA
Formula 500 DLX	0.725	15x121	0.875	96	0.875	120	NA	DOO-R2144-(add size)	NA
Formula 583	0.912	15x121	1.000	120	1.000	144	NA	DOO-R2146-(add size)	NA
Formula S	0.725	15x121	0.875	96	0.875	120	NA	DOO-R2146-(add size)	NA
Formula SL	0.725	15x121	0.875	96	0.875	120	NA	DOO-R2146-(add size)	NA
Formula III	0.912	15x121	1.000	144	1.000	168/192	NA	DOO-R2144-(add size)	NA
Formula III LT	0.912	15x136	1.000	144	1.000	168/192	NA	DOO-R2144-(add size)	NA
Formula Z	0.912	15x121	1.000	144	1.000	168/192	NA	DOO-R2144-(add size)	NA
Grand Touring 500	0.725	15x136	0.875	96	0.875	120	NA	DOO-R2144-(add size)	NA
Grand Touring 583	0.725	15x136	0.875	96	0.875	120	NA	DOO-R2144-(add size)	NA
Grand Touring SE	0.912	15x136	1.000	96	1.000	120	NA	DOO-R2144-(add size)	NA
Mach 1	0.912	15x121	1.000	144	1.000	168/192	NA	DOO-R2144-(add size)	NA
Mach Z	0.912	15x121	1.000	144/168	1.000	168/192	NA	DOO-R2144-(add size)	NA
Mach Z LT	0.912	15x136	1.000	144/168	1.000	168/192	NA	DOO-R2144-(add size)	NA
MX Z 440	0.725	15x121	0.875	96	0.875	120/144	NA	DOO-R2133-(add size)	NA
MX Z 440 Fan	0.725	15x121	0.875	96	0.875	120	NA	DOO-R2133-(add size)	NA
MX Z 583	0.912	15x121	1.000	144	1.000	144/168	NA	DOO-R2133-(add size)	NA
MX Z 670	0.912	15x121	1.000	144/168	1.000	168/192	NA	DOO-R2133-(add size)	NA
Skandic 380	0.912	15x136	1.000	72	1.000	96	NA	DOO-R2146-(add size)	NA
Skandic 500	0.912	15x136	1.000	72	1.000	96	NA	DOO-R2146-(add size)	NA
Skandic SWT	0.912	24x154	1.000	72	1.000	96	NA	DOO-R2146-(add size)	NA
Skandic WT	0.912	20x154	1.000	72	1.000	96	NA	DOO-R2146-(add size)	NA
Summit 500	1.5	15x136	Na	Na	NA	NA	NA	DOO-R2144-(add size)	NA
Summit 583	1.5	15x136	Na	Na	NA	NA	NA	DOO-R2144-(add size)	NA
Summit 670	1.5	15x136	Na	Na	NA	NA	NA	DOO-R2144-(add size)	NA
Touring E	0.725	15x121	0.875	72	0.875	96	NA	DOO-R2146-(add size)	NA
Touring E LT (2)	0.725	15x136	0.875	72	0.875	96	NA	DOO-R2146-(add size)	NA
Touring LE	0.725	15x136	0.875	72	0.875	96	NA	DOO-R2146-(add size)	NA
Touring SLE	0.725	15x136	0.875	72	0.875	96	NA	DOO-R2146-(add size)	NA

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.