

# STUD BOY APPLICATION CHART

## YAMAHA 1997

Riding Style									
Snowmobile Information			Safety		Performance		Wearbars		
1997 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Mountain Lite	1.500	15X136	NA	NA	NA	NA	NA	YAM-R2083-(add size)	NA
Mountain Max 600	1.500	15X136	NA	NA	NA	NA	NA	YAM-R2141-(add size)	NA
Mountain Max 700	1.500	15X136	NA	NA	NA	NA	NA	YAM-R2141-(add size)	NA
Ovation LE	0.510	15X109	0.875	48	0.875	72/96	NA	YAM-R2082-(add size)	NA
Phazer SS	0.740	15X121	0.875	72/96	1.000	96/120	NA	YAM-R2082-(add size)	NA
Venture 500	0.510	15X136	0.875	72/96	0.875	96/120	NA	YAM-R2141-(add size)	NA
Venture 600	0.510	15X136	0.875	72/96	0.875	96/120	NA	YAM-R2141-(add size)	NA
Venture XL	0.510	15X121	0.875	72	0.875	96	NA	YAM-R2141-(add size)	NA
Venture TR	0.510	15X136	0.875	72/96	0.875	96/120	NA	YAM-R2082-(add size)	NA
VK 540 II	0.510	20X156	0.875	62	0.875	93	NA	YAM-R2082-(add size)	NA
VMAX-4 800	0.740	15X121	0.875	144	1.000	192/240	NA	YAM-R2083-(add size)	NA
VMAX 4 Mtn Max	1.500	15X136	NA	NA	NA	NA	NA	YAM-R2083-(add size)	NA
VMAX 500 XT	0.740	15X121	0.875	96	1.000	120	NA	YAM-R2141-(add size)	NA
VMAX 500 XTC	0.740	15X121	0.875	96	1.000	120	NA	YAM-R2141-(add size)	NA
VMAX 600 SX	0.740	15X121	0.875	120	1.000	144	NA	YAM-R2141-(add size)	NA
VMAX 600 XT	0.740	15X121	0.875	120	1.000	144	NA	YAM-R2141-(add size)	NA
VMAX 600 XTC	0.740	15X121	0.875	120	1.000	144	NA	YAM-R2141-(add size)	NA
VMAX 700 SX	0.740	15X121	0.875	144	1.000	192	NA	YAM-R2141-(add size)	NA

\*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**\*\* PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.