

STUD BOY APPLICATION CHART

SKI DOO 1998

Snowmobile Information			Riding Style				Wearbars		
			Safety		Performance				
1998 Model	Lug Height	Track Length	Stud Length	Stud Quantity	Stud Length	Stud Quantity	Deuce	Round	Shaper
Formula 500	0.724	15x121	0.875	96	0.875	120	NA	DOO-R2144-(add size)	NA
Formula 500 DLX	0.724	15x121	0.875	96	0.875	120	NA	DOO-R2144-(add size)	NA
Formula 583 DLX	0.912	15x121	1.000	144	1.000	144/168	NA	DOO-R2144-(add size)	NA
Formula III 600	0.912	15x121	1.000	120/144	1.000	144/168	NA	DOO-R2144-(add size)	NA
Formula III 600 LT	0.912	15x136	1.000	135	1.000	162/189	NA	DOO-R2144-(add size)	NA
Formula III 700	0.912	15x121	1.000	144	1.000	168/192	NA	DOO-R2144-(add size)	NA
Formula S	0.724	15x121	0.875	72	0.875	96/120	NA	DOO-R2146-(add size)	NA
Formula S Electric	0.724	15x121	0.875	72	0.875	96/120	NA	DOO-R2146-(add size)	NA
Formula SL	0.704	15x121	0.875	96	0.875	120	NA	DOO-R2146-(add size)	NA
Formula Z 583	0.912	15x121	1.000	144	1.000	144/168	NA	DOO-R2144-(add size)	NA
Formula Z 670	0.912	15x121	1.000	144	1.000	168/192	NA	DOO-R2144-(add size)	NA
Grand Touring 500	0.724	15x136	0.875	81	0.875	108/135	NA	DOO-R2144-(add size)	NA
Grand Touring 583	0.724	15x136	0.875	108	0.875	135/162	NA	DOO-R2144-(add size)	NA
Grand Touring 700	0.912	15x136	1.000	135	1.000	135/162	NA	DOO-R2144-(add size)	NA
Grand Touring SE	0.912	15x136	1.000	135	1.000	135/162	NA	DOO-R2144-(add size)	NA
Mach 1	0.912	15x121	1.000	144	1.000	168/192	NA	DOO-R2144-(add size)	NA
Mach Z	0.912	15x121	1.000	144/168	1.000	192/240	NA	DOO-R2144-(add size)	NA
Mach Z LT	0.912	15x136	1.000	135	1.000	162/189	NA	DOO-R2144-(add size)	NA
MX Z 440	0.724	15x121	0.875	72/96	0.875	120	NA	DOO-R2133-(add size)	NA
MX Z 500	0.912	15x121	1.000	96	1.000	120/144	DOO-D2152-(add size)	DOO-R2152-(add size)	DOO-S2152-(add size)
MX Z 583	0.912	15x121	1.000	144	1.000	144/168	NA	DOO-R2133-(add size)	NA
MX Z 670	0.912	15x121	1.000	144/168	1.000	168/192	NA	DOO-R2133-(add size)	NA
Skandic 380	0.912	15x136	1.000	81	1.000	108	NA	DOO-R2146-(add size)	NA
Skandic 500	0.912	15x136	1.000	81	1.000	108	NA	DOO-R2146-(add size)	NA
Skandic SWT	0.912	24x154	1.000	91	1.000	91	NA	DOO-R2146-(add size)	NA
Skandic WT	0.912	20x154	1.000	91	1.000	91	NA	DOO-R2146-(add size)	NA
Skandic WT LC	0.912	20x154	1.000	91	1.000	91/122	NA	DOO-R2146-(add size)	NA
Summit 500	2	15x136	Na	Na	NA	NA	NA	DOO-R2144-(add size)	NA
Summit 583	2	15x136	Na	Na	NA	NA	NA	DOO-R2144-(add size)	NA
Summit 670	2	15x136	Na	Na	NA	NA	NA	DOO-R2144-(add size)	NA
Touring E	0.724	15x121	0.875	81	0.875	108	NA	DOO-R2146-(add size)	NA
Touring LE	0.724	15x136	0.875	81	0.875	108	NA	DOO-R2146-(add size)	NA
Touring SLE	0.724	15x136	0.875	81	0.875	108	NA	DOO-R2146-(add size)	NA

*121" Tracks Have 48 Lugs /128" Tracks Have 51 Lugs/ 136" Tracks Have 54 Lugs / 141" Tracks Have 47 Lugs/144" Tracks Have 57 Lugs /156" Tracks Have 62 Lugs

**** PLEASE REMEMBER THAT "DEUCE" BARS ARE SOLD AS SINGLE BARS – NOT AS A PAIR**

Liberty Products, Inc. recommends that tunnel and/or heat exchanger protection be installed in all snowmobiles when traction products are utilized. Even if your snowmobile is equipped with factory tunnel protection we suggest that you check for adequate clearance of traction products before you ride. Riding without performing a clearance check can result in serious damage to your snowmobile. Stud quantity and carbide length must be balanced for safe and proper handling. If you are not using studs do not install overly aggressive wearbars.